


INTRODUCTION TO THE COORDINATE SYSTEM

Assignment: Absolute Coordinates

Use AutoCAD LT software to:

- 1) Set units to decimal.
- 2) Limits, 0,0 for lower left and 25,20 for upper right.
- 3) Follow limits with a zoom, all
- 4) Draw lines that connect the coordinates to reveal a message
- 5) **remember enter or right mouse button will end a line
And ANOTHER enter or right mouse restarts line command.
- 6) Save the file as 01_AbsCI



(draw a)	LINE FROM: (1,14) TO: (1,12) TO: (3,12) TO: (3,14)	(draw a)	LINE FROM: (21,12) TO: (19,12) TO: (19,10) TO: (21,10) TO: (21,14)
(draw a)	LINE FROM: (2,12) TO: (2,10)	(draw a)	LINE FROM: (10,8) TO: (10,3)
(draw a)	LINE FROM: (4,12) TO: (4,10) TO: (6,10) TO: (6,12) TO: (4,12)	(draw a)	LINE FROM: (13,8) TO: (13,3)
(draw a)	LINE FROM: (8,12) TO: (8,10) TO: (10,10) TO: (10,12)	(draw a)	LINE FROM: (12,6) TO: (14,6)
(draw a)	LINE FROM: (13,12) TO: (13,10) TO: (15,10) TO: (15,14)	(draw a)	LINE FROM: (16,8) TO: (16,4)
(draw a)	LINE FROM: (13,12) TO: (15,12)	(draw a)	POINT AT: (16,3)
(draw a)	LINE FROM: (17,12) TO: (17,10)	(draw a)	LINE FROM: (17,8) TO: (17,4)
(draw a)	POINT AT: (17,13)	(draw a)	POINT AT: (17,3)